



GENERAL NOTES:

- 1. HYDRANT NOZZLES SHALL BE LOCATED AT RIGHT ANGLES TO CURB.
- 2. HYDRANTS SHALL BE PLACED 5' FROM ANY UTILITY OR DRAINAGE STRUCTURE OR DITCH FLOW LINE..